

SPARE PARTS LIST

for TYPE 302 LARGE TOP FEED FLOAT CHAMBER

COMPONENT	TYPE 302/1	(Remote) TYPE 302/3	TYPE 302/10	(Remote) TYPE 302/11	LIST PRICE s. d.
	PART NO.	PART NO.	PART NO.	PART NO.	
Complete Float Chamber ..	302/1	302/3	302/10	302/11	70 0
Float Chamber Body only ..	302/001	302/015	302/001	302/015	30 0
Cover complete with Baffle ..	302/002	302/002	302/002	302/002	20 0
Cover Fixing Screws ..	302/009	302/009	302/009	302/009	4
Tickler	302/010	302/010	302/010	302/010	10
Tickler Spring	14/032	14/032	14/032	14/032	2
Tickler Cotter	14/033	14/033	14/033	14/033	1
Tickler Washer	14/189	14/189	14/189	14/189	1
Float	302/004	302/004	—	—	5 0
Float	302/032	302/032	—	—	5 0
Float See note	302/042	302/042	302/042	302/042	5 0
Float Needle	14/320	14/320	—	—	2 0
Float Needle below re	302/035	302/035	—	—	2 0
Float Needle	302/044	302/044	302/044	302/044	2 0
Base Plug and Guide modification *	14/321-2	14/321-2	—	—	3 0
Base Plug and Guide	14/322-302/036	14/322-302/036	—	—	3 0
Base Plug and Guide	302/045-6	302/045-6	302/045-6	302/045-6	3 0
Base Plug Washer	14/252	14/252	14/252	14/252	2
Banjo Single	14/249	14/249	14/249	14/249	3 9
Banjo Twin 90°	14/250	14/250	14/250	14/250	7 6
Banjo Twin 180°	14/251	14/251	14/251	14/251	7 6
Banjo Nut	14/255	14/255	14/255	14/255	1 6
Banjo Washers	14/275	14/275	14/275	14/275	2
Petrol Union Nuts	14/042	14/042	14/042	14/042	9
Petrol Union Nipples	14/026	14/026	14/026	14/026	5
Plug Screw	14/232	—	14/232	—	6
Plug Screw Washer	14/241	—	14/241	—	1
Float Chamber Connection	—	14/219	—	14/219	3 9
Float Chamber Connection Washer	—	14/336	—	14/336	2
Mixing Chamber Connection	—	14/218	—	14/218	2 6
Banjo Connection (for M/ch.)	—	302/057	—	302/057	2 6
Banjo Connection Washer	—	14/336	—	14/336	2
Banjo	—	302/058	—	302/058	3 9
Banjo Washers	—	14/037	—	14/037	2
Banjo Nut	—	302/056	—	302/056	1 6
Base Plug and Guide (Excelsior)	302/069-046	—	302/069-046	—	3 0

*Original part Numbers 302/004, 14/320, 14/321-2 were modified to 302/032, 302/035, 14/322-302/036 since when a further modification was made, i.e., 302/042, 302/044, 302/045-6.

We suggest that parts prior to the last modification should be replaced as an assembly so bringing the float chamber to the latest setting.

GUARANTEE.—The Company take all possible reasonable care in the manufacture and the quality of their products. Purchasers are informed that, any part proved to be defective in manufacture or quality, and returned to the works within six months of its purchase new, will be replaced. The Company must respectfully point out however, that its responsibility and that of its agents, stockists and dealers, is limited to this Guarantee, and that they cannot, under any circumstances, be held responsible for any loss or for any contingent or resulting liability arising through any defect. These conditions of sale and use also apply when the Company's products form part of the original equipment of machines purchased new.

(THIS LIST IS PRINTED IN ENGLAND, AND IS ISSUED SUBJECT TO PRICES RULING AT THE DATE OF DELIVERY).

AMAL LTD., Holdford Road, Witton, BIRMINGHAM, 6
ENGLAND.

TELEPHONE: BIRCHFIELDS 4571 (6 lines).

TELEGRAMS: AMALCARB (PHONE), BIRMINGHAM.

PAGE FOUR

1,000/7/53. W.