



September, 1964.

LIST No. 115/2 (Issue No. 4)

SPARE PARTS FOR

Type G.P.2 RACING CARBURETTOR

(With TYPE 302 RIGID & TYPES 504 & 510 REMOTE FLOAT CHAMBERS)

COMPONENT	FOR T15GP2	FOR T10GP2	FOR T5GP2	FOR T3GP2
Mixing Chamber Body	Specify Engine Engine Details Details Details Details			
Mixing Chamber Top	316/097	316/045	316/049	316/414
Mixing Chamber Cap	316/103	316/046	316/050	316/412
Lock Spring for Mixing Chamber Cap	316/098	316/126	316/048	316/402
Adjuster for Throttle Cable	316/159	316/159	316/159	316/159
Lock Nut for ditto	3369	3369	3369	3369
Throttle Cable Adjuster Sheath	316/083	316/083	316/083	316/083
Throttle Valve (Standard)	316/104	316/010	316/020	316/413
Throttle Valve, opposite Standard, Twin Carbs. ..	316/185	316/013	316/189	—
Throttle Valve Screwed Nipple	5/204	5/204	5/204	5/204
†Throttle Valve Spring	175/308	316/458	316/459	316/466
Jet Needle (Standard)	316/007	316/007	316/146	316/465
Jet Needle (Weak)	316/030	316/030	316/029	316/408
Jet Needle Clip	316/021	316/021	316/021	316/021
Jet Needle Clip Screw	316/015	316/015	316/015	316/015
*Choke Adaptor (Please state bore size)	Not normally supplied separately from M/c. body			
Choke Adaptor Washer	316/100	316/005	316/025	316/462
Choke Adaptor Securing Screws	316/489	316/489	316/489	316/489
Spray Tube	316/067	316/067	316/144	316/144
*Air Tube (Please state bore size when ordering) ..	Not normally supplied separately from M/c. body			
Air Tube Lock Ring	175/115	175/119	175/371	316/411
Main Jet	3326	3326	3326	3326
Jet Holder	15/625	15/625	316/027	316/027
Jet Holder Plug Screw	3348	3348	3348	316/028
Jet Holder Plug Screw	—	185/282	316/028	—
Needle Jet	316/065	316/065	316/065	316/065
Air Valve Cable Adjuster	2626	2626	2626	2626
Lock Nut for ditto	2627	2627	2627	2627
Air Barrel Top	2507	2507	2507	2507
Air Barrel Plug Screw	—	—	—	185/280
Air Valve	2502	2502	2502	2502
Air Valve Spring	2558	2558	2558	2558
Air Valve Nipple Holder	2503	2503	2503	2503
Air Valve Nipple	2629	2629	2629	2629
Air Jet	316/052	316/052	316/052	316/052
Air Jet Plug Screw	316/456	316/456	316/456	316/456
Air Jet Plug Screw Washer	38/023	38/023	38/023	38/023
Pilot Jet	376/076	376/076	376/076	376/076
Pilot Jet Cover Nut	316/494	316/494	316/494	316/494
Pilot Cover Nut Washer	116/162	116/162	116/162	116/162
Pilot Air Adjuster	332/017	332/017	332/017	332/017
Pilot Plug Screws	2403	2403	2403	2403
Pilot Air Adjuster Locknut	332/020	332/020	332/020	332/020
Pilot Air Connection	316/490	316/490	316/490	316/490
Banjo Connection for Remote Float Chamber ..	14/218	14/218	14/218	14/218
Banjo Washer	36/006	36/006	36/006	36/006
Outlet Clip	27/073	27/072	316/421	316/421
Outlet Clip Screw	1962	1962	316/422	316/422
Jet Key	244/1397	244/1397	244/1397	244/1397

†When twin carburettors fitted this component is 75/395 for Type 15, 316/406 for Type 10, and 175/396 for Type 5.
 *These parts are not normally supplied separately as they are machined in position with the mixing chamber body.

**AMAL LTD., HOLDFORD ROAD, WITTON,
 BIRMINGHAM 6, ENGLAND**

'Phone : Birmingham, BIRchfields 4571. Telegrams : "AMALCARB, 'PHONE,
 (P.B.X. 6 lines) BIRMINGHAM."